

DOM Protector[®] : deleting the master card

In General:

With the DOM Protector[®] you have the possibility to delete the master card, which is registered in the cylinder, without sending the cylinder back to DOM. For this process the already registered master card to be deleted has to be available. The process can be done maximally five times, afterwards only DOM can delete the master card.

After deleting the master card the cylinder is in the factory setting again, i. e. all authorizations and events and all programming media (programming cards and PDA's) are deleted. With the DOM Protector[®] online the allocation to the RF-NetManager is also cancelled.

Procedure:

Please follow the steps below to delete the master card:

1. Pull the battery plug (cylinder dead-voltage).
2. Place the master card in the reading area of the antenna and keep it there during the entire procedure.
3. Connect the battery plug.
4. The cylinder first passes through an initialisation sequence (red or green flash of the LED). After approx. 5 seconds the DOM Protector[®] starts to blink red-green by turns. The master card has been deleted successfully. You can now remove it from the reading area. The red-green blinking goes on.
5. Pull the battery plug again (cylinder dead-voltage).
6. After approx. two seconds you connect the battery plug again. The DOM Protector[®] is now back in the factory setting, a new master card can be registered.